

SPUI MARKING DETAILS

NOTES:

- 1. SEE PAVE-900 FOR ARROW AND LEGEND DETAILS.
- 2. SEE PAVE-935 AND PAVE-940 FOR NON-RAMP TURN LANE MARKINGS.
- 3. USE ONLY LEGENDS IN CONJUNCTION WITH ARROWS ON OFF-RAMPS.
- 4. USE TURNING GUIDE LINES FOR ALL TURNING MOVEMENTS. REFER TO PAVE-907 FOR DETAILS.
- 5. FOR OFF-RAMPS USE A 6" WIDTH SOLID WHITE CHANNELIZING LINE BETWEEN LANES THAT WILL TURN IN THE SAME DIRECTION, AND A 12" WIDTH SOLID WHITE CHANNELIZING LINE BETWEEN LANES THAT WILL TURN IN OPPOSITE DIRECTIONS.

NOT TO SCALE

