NOTES

- 1. FOR SHORT-DURATION OR MOBILE OPERATIONS, NO SIGNS ARE REQUIRED IF APPROPRIATELY EQUIPPED VEHICLES ARE USED.
- 2. IF THE OPERATION HAS VEHICLE(S) PARKED ON THE SHOULDER OR VEHICLES ACCESSING THE WORK SITE VIA THE HIGHWAY OR CROSSING THE HIGHWAY TO PERFORM OPERATIONS, A "ROAD WORK AHEAD" SIGN OR AN ARROW BOARD IN CAUTION MODE SHALL BE USED.
- 3. WORK VEHICLES SHOULD BE PARKED AS FAR OFF THE TRAVELED WAY AS PRACTICAL.
- 4. IF THE WORK SPACE IS IN THE MEDIAN OF A DIVIDED ROADWAY, ADVANCE WARNING SIGNS SHALL BE PLACED IN BOTH DIRECTIONS OF TRAVEL.
- 5. VEHICLES AND PERSONNEL SHOULD ALL BE LOCATED AND PARKED ON THE SAME SIDE OF THE ROADWAY TO THE EXTENT PRACTICAL.

