

## DDI MARKING DETAILS

## NOTES:

- 1. SEE PAVE-900 FOR ARROW AND LEGEND DETAILS.
- 2. USE ONLY LEGENDS IN CONJUNCTION WITH ARROWS ON OFF-RAMPS.
- 3. FOR OFF-RAMPS USE A 6" WIDTH SOLID WHITE CHANNELIZING LINE BETWEEN LANES THAT WILL TURN IN THE SAME DIRECTION, AND A 12" WIDTH SOLID WHITE CHANNELIZING LINE BETWEEN LANES THAT WILL TURN IN OPPOSITE DIRECTIONS.
- 4, WHEN THE ON-RAMP ENTRANCE IS A DROP LANE, USE TURN ARROWS AND ONLY LEGENDS IN THE TANGENT/WEAVE SECTION BEFORE THE RAMP CURVES OFF. DO NOT PLACE THE ARROWS OR LEGENDS ON THE RAMP ITSELF.

NOT TO SCALE

